

## 「商話通」簡易操作指南

### SUPERTONE PREMIUM Quick Reference Guide

Features 功能		Activate 啟用	Deactivate 解除
Conference 3 三人會議		<b>FLASH + Tel. No. + FLASH</b>	
Call Forwarding 自動轉駁來電	<ul style="list-style-type: none"> <li>- All Calls 所有來電</li> <li>- Busy 電話使用中</li> <li>- No Answer 無人接聽</li> </ul>	<ul style="list-style-type: none"> <li>- *05 + Tel. No.</li> <li>- *06 + Tel. No.</li> <li>- *07 + Tel. No.</li> </ul>	<ul style="list-style-type: none"> <li>- #05</li> <li>- #06</li> <li>- #07</li> </ul>
Call Park 來電暫泊 ^		<b>FLASH + *25</b>	
Call Park Retrieve 重拾來電 ^		<b>#25 + Ext. No.</b>	
Call Pickup 截聽來電 ^		<b>*24</b>	
Directed Call Pickup 截聽來電(指定內線) ^		<b>*30 + Ext. No.</b>	
Call Transfer 接駁來電		<b>FLASH + Tel. No.</b>	
Call Waiting 來電等候		<b>FLASH</b>	
Last Number Redialling 剛撥號碼重撥		<b># #</b>	
Hold 電話暫候		<b>FLASH + *10</b>	
Store Speed Call 快速撥電儲存		<b>*02 + code (40-69) + Tel. No. + #</b>	
Use Speed Call 快速撥電使用		<b>* + code (40-69)</b>	
Press <b>9</b> for external line and fax if you have subscribed extension dialing 如已選用內線直撥功能，請先按 <b>9</b> 打街線電話或傳真			
^ Features are available only for customer subscribed extension dialing 功能只適用於已選用內線直撥之客戶			