
## T60P SIP Phone Quick User Guide



Quick Guide

## Phone Button





Basic Call Features
Placing a Call Using the handset:  Plick up the handset.  Enter the number, and then press #sesso  Using the speakerphone:  With the handset on-hook, press #sesso  Using the number, and then press #sesso  Using the headset:  With the headset:  With the headset connected, press to activate the headset mode.
Note: During a call, you can alternate between headset, hands-free speakerphone and handset modes by pressing the Headset key or the Speakerphone key or picking up the handset. Headset mode requires a headset connected.
Answering a Call Using the handset: Pick up the handset. Using the speakerphone: Press . Using the headset: Press .
Note: You can ignore an incoming call by pressing the X key.
Ending a Call Using the handset: Hang up the handset or press. Using the speakerphone: Press or . Using the headset: Press .
Press to enter the Dialed Calls list, press or to select the desired call, and then press or #seno.  Press twice when the phone is idle to call the last dialed number.
Call Mute and Un-mute  Press to mute the microphone during a call.  Press again to un-mute the call.
Call Hold and Resume To place a call on hold: Press during an active call.

To resume the call, do one of the following:
• If there is only a call on hold, press
• If there is more than one call on hold, press to select the desired call, and then press
Call Transfer You can transfer a call in the following ways: Blind Transfer  1. Press during an active call. The call is placed on hold.  2. Enter the number you want to transfer to.  3. Press
Semi-Attended Transfer  1. Press during an active call. The call is placed on hold.  2. Enter the number you want to transfer to, and then press when you hear the ring-back tone.
Attended Transfer  1. Press during an active call. The call is placed on hold.  2. Enter the number you want to transfer to, and then press when the second party answers.
Call Conference
<ol> <li>Press during an active call. The call is placed on hold.</li> <li>Enter the number of the second party, and then press second.</li> <li>Press again when the second party answers. All parties are now joined in the conference.</li> <li>Hang up the handset to disconnect all parties.</li> </ol>
Voice Message The Message Waiting Indicator on the idle screen indicates that you have new voice messages waiting. The Message key LED lights up. To listen to voice mail messages:  1. Press
Call History  1. Press when the phone is idle, press or voto scroll through the list.  2. Select an entry from the list, you can do the following:  Press to place a call.  Press to add the entry to the local directory.  Press to delete the entry from the list.
Volume Adjustment

• Press or during a call to adjust the receiver volume of handset/speakerphone/headset.

• Press or when the phone is idle to adjust the ringer volume.